




1/14



F16, 1







FIG. 2


SWITCHING PATTERN

| | ANTENNA A | ANTENNA B | ANTENNA A ANTENNA B ANTENNA C ANTENNA D | ANTENNA D |
|-----------|-----------|-----------|---|-----------|
| PATTERN 1 | fA | fB | £C | fD |
| PATTERN 2 | fD | ۲Ą | fB | fC |
| PATTERN 3 | fC | QJ | fА | fB |
| PATTERN 4 | fB | ЭJ | fD | ٧J |

FIG. 3




F <u>I</u> G. ,



SWITCHING PATTERN

| | ANTENNA A | ANTENNA B | ANTENNA C | ANTENNA D |
|-----------|-----------|-----------|-----------|-----------|
| PATTERN 1 | fA | fВ | 1C | QJ |
| PATTERN 2 | fD |)J | fВ | ¥Э |

FIG. 6



. 16. /




FIG. 8

| | 2 | Ξ | |
|---|----------|-------------------|--|
| C | 2 | _ | |
| L | 1 | ı | |
| ۲ | - | - | |
| ۲ | - | _ | |
| | - | _ | |
| - | - | ١. | |
| c | 2 | _ | |
| c | 2 | _ | |
| | 2 | _ _ _ | |
| | <u>ک</u> | `- ≥ | |
| | בֿ | \- - | |
| | ב | | |
| | ב | | |
| | 2 | | |
| | 7 | | |
| | | | |
| | | シンコー・マー フトゴーラーすどう | |
| | | | |
| | | | |
| | | L DITION TAND | |
| | | | |


| | S1 | 25 | 83 | 84 |
|-----------|------------------------|------------------------|--|------------------------|
| PATTERN 1 | TRANSMISSION DATA A | TRANSMISSION DATA B | TRANSMISSION DATA C | TRANSMISSION DATA D |
| PATTERN 2 | TRANSMISSION DATA D | TRANSMISSION DATA A | TRANSMISSION TRANSMISSION DATA B | TRANSMISSION DATA C |
| PATTERN 3 | | TRANSMISSION DATA D | TRANSMISSION TRANSMISSION TRANSMISSION TRANSMISSION DATA D DATA D DATA B | TRANSMISSION DATA B |
| PATTERN 4 | | TRANSMISSION DATA C | TRANSMISSION TRANSMISSION TRANSMISSION DATA B DATA C DATA D | TRANSMISSION DATA A |

FIG. 9

SYNTHESIZER FREQUENCY SWITCHING TIMING

| S4 | (J | ЭJ | ŧВ | fλ | OJ · |
|-----|--------|----|----|----|------|
| 83 |) J | fB | fА | fD | ЭJ |
| 25 | fB | fΑ | fD | fC | fB |
| \$1 | fÀ | fD | £C | fB | fA |
| | 11 | 12 | T3 | T4 | T5 |

FIG 10



- 5




FIG. 12

SYNTHESIZER FREQUENCY SWITCHING TIMING

| | ANTEN | ANTENNA A | ANTEN | ANTENNA B | ANTENNA C | NA C | ANTENNA D | INA D |
|----|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|
| | S11 | \$12 | \$21 | \$22 | \$31 | \$32 | 841 | 842 |
| = | fA | FREQUENCY SWITCHING | fB | FREQUENCY SWITCHING | ЭJ | FREQUENCY SWITCHING | fD | FREQUENCY SWITCHING |
| T2 | FREQUENCY SWITCHING | fD | FREQUENCY SWITCHING | fA | FREQUENCY SWITCHING | fB | FREQUENCY SWITCHING | fC |
| T3 | fC | FREQUENCY SWITCHING | fD | FREQUENCY SWITCHING | fА | FREQUENCY SWITCHING | fB | FREQUENCY SWITCHING |
| 4 | FREQUENCY SWITCHING | 串 | FREQUENCY SWITCHING |)J | FREQUENCY SWITCHING | fD | FREQUENCY SWITCHING | fA |
| T5 | fA | FREQUENCY SWITCHING | fB | FREQUENCY SWITCHING | fC | FREQUENCY SWITCHING | fD | FREQUENCY SWITCHING |
| | | | | | | | | |

